

Hanging instructions

Preparation: Only use rolls of the same batch. Before hanging verify that the wallpaper does not have any defects. To check it, please to roll out the wallpaper on a flat and clean surface. Claims after hanging will not be accepted!

Surface pre-treatment: The surface has to be dry, sustainable, flat, clean, evenly absorbing and color neutral. Old wallpaper has to be removed completely! Rough underground, holes and unevenness have to be glazed and closed. For leveling the absorption you have to use a water-based primer.

Since a successful hanging result is only possible on a neutral colored underground use a rolled maculation or white-colored primer. In case of a non-absorbent underground we advise to hang a non-woven lining material before you install the wallpaper. On this underground you can hang (as explained below) your wallpaper.

Paste: We advise to use special paste for non-woven wallpaper that came with your custom printed wallpaper: "Metylan direct control" produced by HENKEL, Germany. To prepare the paste for the installation, please follow the instructions on the sachet. The non-woven wallpaper can be applied by using the "paste the wall" technique: apply paste directly onto the wall and then hang the wallpaper on pasted wall, butt joined and without any soaking time. The paste should be applied with a short-haired roll per panel and it should cover a little more than the width of the wallpaper.

Attention: Remove any excess paste with a damp sponge immediately. Otherwise it is possible that you can see a grey film after drying.

Hanging the wall covering: On each panel top you can see the order number of the panel. Panel no 1 is always the first panel from the left. Ideally start installing the wallpaper from the left side of the wall.

The wallpaper should be installed vertically (using a spirit level or similar) from the top to the bottom. Press the wallpaper onto the wall, butt joined, using a foam rubber roller/wallpaper brush and a clean soft damped cloth. Remove carefully any air bubbles by from the middle to the sides.

Cut off excess wallpaper with a cut ruler und a cutter knife directly on the wall.

Caution: Please do not use rough brushes or any hard plastic rollers. The wallpaper can be damaged by solid hitting or pulling. We cannot give any warranty for form stability and damages of the material if case of using wallpaper pasting machines. During the process of drying, overly intense heating and/or draughts can cause the seams to open up.

How to remove the wallpaper: Our wallpaper is dry-strippable panel-by-panel if the preparations of the surface have been followed as mentioned above. In cases where too much of the wallpaper has been applied during the installation, use a damp sponge and moisten the wallpaper. After one or thwo inutes the paste has softened and it should be easier to remove the wallpaper without damage. You can dispose old wallpaper and left-over paste with the household waste.

For hanging our wallpaper you need the following: Non-woven wallpaper paste as delivered with your wallpaper, bucket, stirring staff, sharp cutting knife, metal cutting ruler, water-level/a plumb-line, pencil, foam rubber roller/soft wallpaper brush, soft clean cloth, sponge and ladder.

Advice: The above mentioned indications are meant as general recommendations. No liability is assumed for conditions out of our control such as working conditions, condition and character of the surface. In case of doubt we advise adequate trials, before starting the hanging job.

Enjoy your new wallpaper.