

Introducing Pure White to the Saturn Collection



SATURN COLLECTION

Current Rating - Power point	10A
Current Rating - Switches	20A/16AX
Voltage	250V a.c.
Fascia Colours	PW (Pure White) EB (Espresso Black) OM (Ocean Mist)
Edge and Base Colour	Black
Dolly and Socket Colour	Arctic Silver
Bezel Colour	Chrome

Clipsal Saturn LED and Labelling Options

Clipsal Saturn is available with or without LED light indication. The LED offers a subtle blue glow that can be configured to come on when the switch is turned on, or it can come on when the switch is turned off, or it can remain permanently on as a switch locator for when you get caught in the dark.

Clipsal Saturn switches also have the option of being able to be fitted with handy labelled buttons, making it easy to select the right switch every time.




4000VH1 Mounting Frames

The standard base colour is black. However mounting frames can be used to complement the wall colour and decor. Frames come in five colours: White, Desert Sand, Cream, Black and Soft Grey. Attach the 4000VH1 to the back of the switch for a seamless look and finish.

Colours and Styles

Available in Espresso Black, Ocean Mist and Pure White for all switches, switched sockets, dimmers, cooker switches, and communication plates.




BLANK PLATES



4060VX, PW
Blank Plate, Pure White

ARCHITRAVE SWITCHES



4061AL, PW
Architrave Switch Plate, 1 Gang, Pure White, 20A/16AX, 250V a.c.

4062AL, PW
Architrave Switch Plate, 2 Gang, Pure White, 20A/16AX, 250V a.c.

PUSH-BUTTON SWITCHES



4061PB, PW
Push-button Switch, 1 Gang, Push-button, Pure White, 20A/16AX, 250V a.c.



4062PB, PW
Push-button Switch, 2 Gang, Push-button, Pure White, 20A/16AX, 250V a.c.



4063PB, PW
Push-button Switch, 3 Gang, Push-button, Pure White, 20A/16AX, 250V a.c.



4064PB, PW
Push-button Switch, 4 Gang, Push-button, Pure White, 20A/16AX, 250V a.c.

LED PUSH-BUTTON SWITCHES



4061PBL, PW
Push-button Switch, 1 Gang, Push-button, LED, Pure White, 20A/16AX, 250V a.c.



4062PBL, PW
Push-button Switch, 2 Gang, Push-button, LED, Pure White, 20A/16AX, 250V a.c.



4063PBL, PW
Push-button Switch, 3 Gang, Push-button, LED, Pure White, 20A/16AX, 250V a.c.



4064PBL, PW
Push-button Switch, 4 Gang, Push-button, LED, Pure White, 20A/16AX, 250V a.c.



4065PBL, PW
Push-button Switch, 5 Gang, Push-button, LED, Pure White, 20A/16AX, 250V a.c.



4066PBL, PW
Push-button Switch, 6 Gang, Push-button, LED, Pure White, 20A/16AX, 250V a.c.

FAN CONTROLLER



4061VF3CSF, PW
Fan Speed Controller, 3 Speed, Pure White, 250V a.c., 75VA.

DIMMER



4062E450UD, PW
Dimmer, Universal, Rotary Control, Separately Switched. 2 Gang Grid Switch & Dimmer Assembly, Pure White, 220-240V a.c., 450W

COOKER SWITCH




4061/45, PW
Single Pole, 45A, Push-button, Cooker Switch, Pure White


COMMUNICATION WALL PLATES




4031VH, PW
Vertical/Horizontal 1 Gang Grid & Plate Assembly, Pure White



4032VH, PW
Vertical/Horizontal 2 Gang Grid & Plate Assembly, Pure White



4033VH, PW
Vertical/Horizontal 3 Gang Grid & Plate Assembly, Pure White



4034VH, PW
Vertical/Horizontal 4 Gang Grid & Plate Assembly, Pure White

SWITCHED SOCKETS



4015, PW
Single Gang Switched Socket, 250V a.c., 10A, Pure White



4015L, PW
Single Gang Switched Socket, 250V a.c., 10A, Pure White



4025, PW
Power Outlet Double 250V a.c., 10A, Pure White



4025X, PW
Power Outlet Double 250V a.c., 10A, Extra Switch, Pure White



4025H2, PW
Power Outlet, 4 Gang, 250V a.c., 10A, (2 x double), Pure White



Clipsal Australia Pty Ltd

A member of Schneider Electric

Head Office

33-37 Port Wakefield Road,
Gepps Cross, South Australia 5094

Website clipsal.com

Contact us clipsal.com/feedback

National Customer Care Enquiries:

1300 2025 25

National Customer Care Facsimile:

1300 2025 56

♻️ printed on recycled paper

International Enquiries

International Sales and Marketing

Email export@clipsal.com.au

Schneider Electric (NZ) Ltd

38 Business Parade South, Highbrook,
East Tamaki, Manukau 2013,
NEW ZEALAND

Telephone + 64 9 829 0490

Facsimile + 64 9 829 0491

Website www.schneider-electric.co.nz

Clipsal Customer Care

Freephone 0800 652 999

Freefax 0800 101 152

Email sales@nz.schneider-electric.com

Website www.clipsal.co.nz

You can find this brochure and many others online in PDF format at:

clipsal.com/brochures

clipsal.com/saturn

Clipsal Australia Pty Ltd reserves the right to change specifications, modify designs and discontinue items without incurring obligation and whilst every effort is made to ensure that descriptions, specifications and other information in this catalogue are correct, no warranty is given in respect thereof and the company shall not be liable for any error therein.

© Clipsal Australia Pty Ltd